

Diaphragm Differential Switch

Series DPD1T, DPD2T

Features

- ▶ High reliability
- ▶ Dual switching capability
- ▶ High accuracy
- ▶ Tamper-proof external adjustment
- ▶ NEMA 4

Applications

- ▶ Pump & compressor monitoring
- ▶ HVAC systems
- ▶ Engine monitoring
- ▶ Machine tools
- ▶ Hydraulic power units
- ▶ Filtration systems
- ▶ Metal working
- ▶ Utility & power generation



General Specifications*


Electrical Characteristics:	All models incorporate Underwriters Laboratories, Inc. and CSA Listed single pole double throw snap-action switching elements.
Accuracy:	± 0.5% of the adjustable range
Switch:	
Type:	SPDT snap action; single or dual circuit
Rating:	10 amps @ 125/250 VAC; 3 amps @ 480 VAC (Class A or H limit switch). Consult product configurator for ratings of optional limit switches.
Wetted Parts:	
Diaphragm:	17-7 PH stainless steel
Seals:	Viton®
Enclosure:	Die-cast aluminum anodized
Other Parts:	Nickel plated aluminum 300 series stainless steel
Electrical Connection:	Screw terminals on covered terminal strip through 1/2" NPT conduit fitting
Enclosure Ratings:	NEMA 4
Pressure Connection:	1/8" NPT female high + low

* See product configurator for additional options.

Approvals/Listings:	
PED (European):	Compliant to PED 97/23/EC
Temperature Range:	
Operating:	-65°F to +165°F (-54°C to +74°C)
Adjustment Instructions:	
Pressure:	Turn adjustment screw clockwise to decrease pressure difference; counterclockwise to increase pressure difference
Vacuum Differential:	Turn adjustment screw counterclockwise to decrease vacuum difference; clockwise to increase vacuum difference
Options:	-Factory pre-set -NEMA 4X enclosure
Shipping Weight:	Single & dual - approximate 3.50 lbs.

Wiring Diagram

(contact status at atmospheric pressure)




Wiring Code

Lead	Circuit #1		Circuit #2	
	Pressure	Vacuum	Pressure	Vacuum
Normally Closed	Blue	Red	Orange	Yellow
Common	Purple	Purple	Brown	Brown
Normally Open	Red	Blue	Yellow	Orange

Diaphragm Differential Switch

Series DPD1T, DPD2T

Technical Drawing



Product Configurator

Example **DPD1T** **-A** **3SS**

* Highlighted options represent those most frequently used.
Select these common options for improved availability. (5/21)

H Hermetically sealed limit switch option - Class I, Division II (requires AA, CC or HH limit switch)

Base Configuration

DPD1T	Single setpoint housed
DPD2T	Dual setpoint housed

Limit Switch¹

-A	10 amps @ 125/250 VAC; 3 amps @ 480 VAC; (standard for pressure range 3SS, 80SS or 150SS)
-H	10 amps @ 125/250 VAC; 3 amps @ 480 VAC; (standard for pressure range 18SS)
-M	10 amps @ 125/250 VAC; 3 amps @ 480 VAC; 0.5 amps @ 125 VDC; 0.25 amps @ 250 VDC
-GH	1 amp @ 125 VAC; with gold contacts
-GH	Hermetically sealed; 1 amp @ 125 VAC with gold contacts (not available on vacuum models)
-HH	Hermetically sealed; 5 amps @ 125/250 VAC (not available on vacuum models)

Options

-FX	NEMA 4X enclosure
-L6	6-contact terminal block (DPD2T only)
-CS	CSA approved
-Sxxx	Factory preset (consult factory)

Adjustable Range

	Working Range	Adjustable Range (PRESSURE) ³				Approx. Deadband ² (Actuation Value)	Max. Diff. Pressure (Proof)
		Decreasing - psi (bar)		Increasing - psi (bar)			
	psi (bar)	Min	Max	Min	Max	psi (bar)	psi (bar)
3SS	.03-10	.03 (.00)	2.76 (.2)	.27 (.02)	3 (.2)	.09 - .24 (.01 - .02)	10 (.7)
18SS	.4-60	.4 (.03)	17.68 (1.2)	.72 (.05)	18 (1.2)	.18 - .32 (.01 - .02)	60 (4.1)
80SS	.5-160	.5 (.03)	75.3 (5.2)	5.2 (.4)	80 (5.4)	2.2 - 4.7 (.1 - .3)	160 (10.9)
150SS	1.5-300	1.5 (.10)	141.3 (9.7)	10.2 (.7)	150 (10.2)	3.5 - 8.7 (.2 - .6)	300 (20.4)

	Working Range	Adjustable Range (VACUUM) ⁴				Approx. Deadband ² (Actuation Value)	Max. Diff. Pressure (Proof)
		Decreasing (In. Hg)		Increasing (In. Hg)			
	In. Hg	Min	Max	Min	Max	In. Hg	In. Hg
3SS	.06-20	0.06	5.49	0.57	6	.17 - .51	20
18SS	.8-30	0.8	29	1.8	30	.44 - 1.00	30

NOTES:

¹ Consult supplementary guide for specific deadband values

² Deadband values indicated when used with the "standard" limit switch

³ Working range may be extended to 400 psi provided the maximum differential pressure (proof) is not exceeded

⁴ Working range may be extended to 30 in.Hg provided the maximum differential pressure (proof) is not exceeded